
400
410
START
420
RECEIVE INITIALIZATION SIGNAL
430
ACTIVATE ACOUSTIC CIRCUITRY
440
RECEIVE AUDIO SIGNAL
450
A/D CONVERSION
460
TRANSMIT DIGITAL SIGNAL TO MOBILE DEVICE

FIG. 4