
PULSER/RECEIVER
15A
TRANSDUCER
15B
FINGERS
INITIAL PULSE
FINGER ECHO
BACK SURFACE ECHO
0
2
4
6
8
10
12

FIG.7