
START
EVACUATE THE NEGATIVE-PRESSURE BARREL
502
ARM A TRIGGER VALVE SITUATED BETWEEN THE CHAMBER AND THE OPEN PROXIMAL END OF THE ACCELERATOR BARREL
504
CONFIGURE A MICRO-PARTICLE WITHIN THE ACCELERATOR BARREL AT A LAUNCH POINT PROXIMATE TO THE TRIGGER VALVE
506
ABRUPTLY RELEASE THE ARMED TRIGGER VALVE TO ABRUPTLY RELEASE PRESSURIZED GAS FROM THE CHAMBER AND INTO THE OPEN PROXIMAL END OF THE ACCELERATOR
508
DRAW AT LEAST A PORTION OF BLOOD FROM THE MOMENTARY, MICRO-ERUPTION INTO THE EVACUATED NEGATIVE-PRESSURE BARREL THROUGH THE PIERCED APERTURE
510
END

FIG. 5