
F
FROM FIG. 11
Set Reel Parameters
278
Spin Reels
Activate Video Playback
Playback=True
Activate Digitally Enhanced Sound
Sound=True
Activate External Lamps
Lamps=True
280
282
Spin Successful?
No
Yes
284
Prior State = Spin
State = Evaluate
290
Any Other Tilts?
Yes
Prior State = Spin
State = Tilt
288
No
170
A
TO TOP OF FIG. 11

FIG. 15