
200
TRACK TOUCH SCREEN
202
DETERMINE STATE OF TOUCH SCREEN DISPLAY
204
CHECK FOR GESTURING
206
CHANGE TACTILE PIXEL(S) IN RESPONSE TO PREDETERMINED STATE OR GESTURE
208

Fig. 2


100
101
126
CMD
104

Fig. 3