FIG. 3


50
DETECT A TOUCH INPUT APPLIED TO A TOUCH SENSITIVE DISPLAY
52
IN RESPONSE, CAUSE SELECTION OF AN ITEM DISPLAYED ON THE TOUCH SENSITIVE DISPLAY AND DISPLAY A TOUCH OPERABLE COMMAND OR COMMANDS ON THE TOUCH SENSITIVE DISPLAY THAT ARE EXECUTABLE UPON THE ITEM
54