FIG. 3


start
S310
has user set manner mode manually ?
yes
no
S320
motion ?
yes
no
S330
horizontal ?
yes
no
activate time
S340
S350
has predetermined time elapsed ?
no
yes
switch mobile terminal to manner mode
S360
S370
motion ?
no
yes
cancel manner mode
S380
end