
start
Sense output node
502
504
Voltage sensed?
n
y
Actuator in passive mode
506
n
Sensed voltage greater than threshold?
508
y
Actuator in active mode
510
Retrieve haptic profile
512
Generate haptic response by actuator based on retrieved haptic profile
514
518
Set to passive mode
y
Haptic respone complete?
n
516
500
stop

Fig. 5