FIG. 6


START
S61
SELECT MODE ?
NO
YES
S62
TOUCH INPUT ?
NO
YES
S63
DISPLAY MODE ICON
S64
MOVE TOUCH AREA ?
NO
YES
S65
EXTRACT VALUE OF TOUCH AREA MOVEMENT
S66
EXECUTE FUNCTION OF SELECTED MODE CORRESPONDING TO EXTRACTED VALUE OF TOUCH AREA MOVEMENT
S67
DISPLAY DISPLACEMENT VALUE GENERATED BY EXECUTING FUNCTION OF SELECTED MODE
S68
TOUCH INPUT DISCONTINUED ?
NO
YES
S69
ERASE MODE ICON
END