
Power management system activated.
Check temperature.
Temperature greater than Optimal Temperature.
Yes
No
Activate cooling element.
Has temperature changed?
No
Yes
Deactivate the cooling element.

FIG. 10a