
Movable part touched by user
Haptic Device
Actuator motion, pushes the movable part
Pen Type Mobile Apparatus 100

Fig.8