FIG. 10


Flex distribution control
Controlled by polarity of current
High flex density areas
N
N
Controlled by geometry of core heads
S
N
Spread
High flex density area
S
N
spot