FIG. 12


PACKET 1 (Address = 0x00000000, data1)
EXECUTE AS A COMMAND FOR LCDCNT10
PACKET 2 (Address = 0x00001000, data2)
TRANSFER TO SLCDCNT12 AS A COMMAND FOR SLCDCNT12
PACKET 3 (Address = 0x00001001, data3)
TRANSFER TO SLCDCNT12 AS A COMMAND FOR SLCDCNT12
PACKET 4 (Address = 0x00000001, data4)
EXECUTE AS A COMMAND FOR LCDCNT10
PACKET 5 (Address = 0x00000002, data5)
EXECUTE AS A COMMAND FOR LCDCNT10