
610
612
Device powers on
614
CE device identifies antenna systems
616
Discover one or more other antenna systems
620
Antenna system detected?
N
622
No antenna systems / Terminate
Y
624
Determine coupling parameters
626
Previously coupled?
N
630
Store configuration instructions
632
Enable / disable services
Y
628
Re-establish configuration

FIG. 6