
DISPLAY
106
DISPLAY CONTROLLER
108
TV TUNER
102
104
CAMERA
100
RF TRANSCEIVER
94
96
98
BATTERY
124
BATTERY MANAGEMENT
122
MEMORY
110
FLASH MEMORY
112
EXTERNAL MEMORY
114
ANALOG/DIGITAL BASEBAND PROCESSOR (CPU)
72
GPS
90
92
VIBRATOR
88
SIM CARD
116
WLAN
76
FM TUNER
72
74
USB
78
AUDIO CODEC
80
82
84
KEYPAD
86
USB POWER
118
AC/DC ADAPTER
120
MOBILE DEVICE/CELLULAR PHONE/PDA
70

FIG.3