
1100
DETECT INITIATION OF GAME
1105
ROTATE DISPLAY DEVICE(S)
1110
DETERMINE INDICIA DEFINING OUTCOME OF GAME
1115
DETERMINE SURFACE LOCATION(S) OF DISPLAY DEVICE(S) TO BE ALONG PAYLINE
1120
SURFACE LOCATION(S) DISPLAYING DETERMINED INDICIA?
1125
YES
NO
DETERMINE WHEN DETERMINED SURFACE LOCATION(S) NOT VIEWABLE BY PLAYER
1130
CHANGE DISPLAYED INDICIA TO DETERMINED INDICIA AT DETERMINED SURFACE LOCATION(S)
1135
STOP ROTATING DISPLAY DEVICE(S) TO DISPLAY DETERMINED INDICIA ALONG PAYLINE
1140

FIG. 11