FIG. 21


500
START
(1)
501
OPERATION END CONDITION SET?
YES
511
END
NO
NO
P>=P1 ?
502
(2)
YES
NO
TOUCH MOVABLE OBJECT?
503
YES
510
RETURN OBJECT TO INITIAL POSITION
MOVE SELECTION FRAME TO TOUCHED POSITION
504
(3)
YES
P<P1 ?
505
NO
506
P>=P2 ?
NO
YES
507
TOUCHED POSITION WITHIN AREA OF OPTION?
NO
YES
SELECT OPTION FOR ACTIVATION
508
(4)
CHANGE DISPLAY
509