
EPS network 294
RRC EPS 202
Local area network (sub-system) 112B
RRC Idle 204
EPS RRC Connection management 206
RRC_Connected 208
Data transfer 210
Detect local network 212
eRRC 214
Establish eRRC for local area network {Create SAP} 216
eRRC 218
eRRC establish complete {Confirm SAP} 220
222A
SAP
222B
RRC Connection management 224
Data transfer
Data transfer
226
Remove eRRC for local area network {Close SAP} 228
222B
SAP closed 232
222A
Delete eRRC 236
Data transfer 240
EPS RRC Connection release 246
RRC Idle 248

FIG. 2