
Start
a virtual disk 121 is shown on screen
201
after receiving a movement signal from a control button 11, a moving mark 122 moves from the "origin" 124 to a desired location along fixed marks 123
202
203
confirmation signal cancelled?
Yes
No
after activating a corresponding fixed mark 123, the moving mark 122 returns to the "origin" 124 after traversing periphery of the virtual disk 121 and a speaker 13 makes a dialing sound
204
receive all moving signals
205
end

FIG. 2