
LCD DISPLAY
218
MS3
MEMORY STICK
223
TRANSMISSION/ RECEPTION CIRCUIT
263
214
MICROPHONE
221
SPEAKER
217
LCD CONTROLLER
255
IMAGE DECODER
256
MULTIPLEXER/ DEMULTIPLEXER
257
RECORDING/ REPRODUCING SECTION
262
MODULATION/ DEMODULATION CIRCUIT
258
AUDIO CODEC
259
260
261
POWER SUPPLY CIRCUIT
251
MAIN CONTROLLER
250
FLASH MEMORY
250a
OPERATION INPUT CONTROLLER
252
IMAGE ENCODER
253
CAMERA I/F
254
TO EACH SECTION
OPERATION KEYS
219
JOG DIAL
222
CCD CAMERA
216

FIG. 23