FIG. 23


WAITING STATE DISPLAY CONTROL
S51
WAITING STATE?
NO
YES
S52
TURN OFF LAMP
S53
DISPLAY MENU
S54
PLAYER EXIST?
NO
YES
S55
SELECTED?
NO
YES
S56
COIN DEPOSITED?
NO
YES
S58
START GAME?
YES
NO
S59
DISPLAY SELECTED CONTENT
S57
END WAITING STATE
RETURN