
601
START
600
605
ACCEPT LIGHT
610
PROPAGATE LIGHT
615
OUTPUT LIGHT
620
END (STATE OF CIRCUIT INDICATED VISUALLY TO OBSERVER)

FIG. 6