
Basic OS Utilities
33
Basic OS
31
Basic OS Drivers
34
HD Partition
131
Basic OS Booting Procedure
32
Booting Procedure Module
44
PDA Booting Procedure
42
PDA OS Utilities
41
PDA OS
40
PDA OS Drivers
43
HD Partition
132
13

FIG. 3