FIG. 4


SPEAKER
21R,21L
PANEL DISPLAY UNIT
5
91
97
VIDEO RAM
98
IMAGE CONTROL IC
96
IMAGE ROM
92
IMAGE CONTROL CPU
93
94
95
IMAGE CONTROL WORK RAM
IMAGE CONTROL PROGRAM ROM
IN PORT
89
POWER AMPLIFIER
88
SOUND SOURCE IC
WORK RAM
PROGRAM ROM
90
OUT PORT
85
86
SUB-CPU
84
83
IN PORT
87
82
MAIN CONTROL CIRCUIT
CROSS BUTTON
○ BUTTON
x BUTTON
81
26
27
28