
800
Start
810
Display Keypad of Touch Screen
820
Inflate Button(s) corresponding to Key(s) of Keypad
830
Sense Location(s) of Touch Screen Depressed
840
Output Coordinates of Sensed Location(s)
850
No
Does Sensed Location(s) correspond to an "EXIT" Key?
860
Yes
Deflate Button(s)
870
End
880

FIG. 8