
1300
Detect user movement or physical engagement of touch surface
1302
Activate electrically-deformable material
1304
Move touch surface

Fig. 13