
1000
Start
1002
Stylus engage touchscreen?
No
Yes
1004
Button depressed on stylus?
No
1006
Execute a first command
Yes
1008
Execute a second command

Fig. 10