FIG.13


START
RECEIVE THE IMAGE SIGNAL NEEDED FOR IMAGE DISPLAY OF THE DISPLAY APPARATUS
S100
GENERATE THE DIMMING SIGNAL ON THE BASIS OF BRIGHTNESS OF THE RECEIVED IMAGE SIGNAL
S110
TRANSMIT THE GENERATED DIMMING SIGNAL TO THE EXTERNAL LIGHTING DEVICE
S120
ADJUST BRIGHTNESS OF THE EXTERNAL LIGHTING DEVICE ACCORDING TO THE DIMMING SIGNAL
S130
ADJUST BRIGHTNESS OF THE OUTPUT IMAGE OF THE DISPLAY APPARATUS ON THE BASIS OF THE GENERATED DIMMING SIGNAL
S135
END