Fig. 3


12a
12b
18
12c
INSERT COINS
CREDIT
25¢
LINES
BET
TOTAL BET
PAID
Collect
Help
Pay Table
Select Lines
Bet Per Line
Spin Reels
Max Bet Spin
26

Fig. 4


12a
12b
18
12c
GOOD LUCK
ANY THREE
in any position starts the "Jackpot Party" bonus round
All pays awarded left to right only.
22a
22b
22c
22d
22e
500
CREDIT
25¢
5
LINES
BET
35
TOTAL BET
0
PAID
Collect
Help
Pay Table
Select Lines
Bet Per Line
Spin Reels
Max Bet Spin
26