
901
No Fingers Down
when: Two fingers press down at same time
902
Precision-Hover Mode
when: Fingers MOVE
912
Finger movements reposition the cursor
when: 3rd finger taps briefly
911
Generate LEFT DOWN Mouse Event
when: 3rd finger taps briefly
903
Left mouse button is down
when: Fingers MOVE
914
Finger movements cause the cursor to be moved (centered between the two fingers that are down) with the left mouse button still depressed.
913
Generate LEFT UP Mouse Event
when: Stop touching with all fingers

FIG. 9