
801
No Fingers Down
when: One finger DOWN
802
One Finger Down Mode
when: One Finger immediately lifted UP
811
Generate Left CLICK
when: Immediately tap with a 2nd finger
803
Pending Right or Middle button mode
812
Generate MIDDLE DOWN Mouse Event
when: Immediately tap with a 2nd finger
804
Middle mouse button mode
814
Finger movements reposition the cursor with the middle mouse button still depressed (e.g. middle-dragging)
when: Fingers MOVE
813
Generate MIDDLE UP Mouse Event
when: Stop touching with all fingers

FIG. 8