800


810
GENERATE ON-SCREEN DISPLAY
820
DETECT MOVEMENT OF FLIP INTERFACE
830
TRANSLATE MOVEMENT OF FLIP INTERFACE INTO CHANGES IN THE ON-SCREEN DISPLAY

FIG. 8