
150
154
DISPLAY
SCREEN DRIVER
156
KEYPAD
162
ACCELERATOR
164
CPU
160
MEMORY
DECELERATOR
158
166
152
174
180
TOUCH SENSITIVE SURFACE
SCREEN ELEMENT DIRECTION
TOUCH SENSITIVE SURFACE
176
DETECTOR
TOUCH SENSITIVE SURFACE
184
182
178

FIG. 7