FIG. 27


POWER-ON
S432
HAVE L, R AND START BUTTONS SIMULTANEOUSLY DEPRESSED ?
NO
YES
RESET X COUNTER AND Y COUNTER
S434

FIG. 28


POWER-ON
RESET X COUNTER AND Y COUNTER
S442
END