

template extension reactions, quantitative RT-PCR, Molecular Beacons, and Invader assays, these are described briefly below.

**[0078]** FRET and template extension reactions utilize a primer labeled with one member of a donor/acceptor pair and a nucleotide labeled with the other member of the donor/acceptor pair. Prior to incorporation of the labeled nucleotide into the primer during an template-dependent extension reaction, the donor and acceptor are spaced far enough apart that energy transfer cannot occur. However, if the labeled nucleotide is incorporated into the primer and the spacing is sufficiently close, then energy transfer occurs and can be detected. These methods are particularly useful in conducting single base pair extension reactions in the detection of single nucleotide polymorphisms and are described in U.S. Pat. No. 5,945,283 and PCT Publication WO 97/22719.

**[0079]** Quantitative Real Time PCR. A variety of so-called “real time amplification” methods or “real time quantitative PCR” methods can also be used to determine the quantity of a target nucleic acid present in a sample by measuring the amount of amplification product formed during or after the amplification process itself. Fluorogenic nuclease assays are one specific example of a real time quantitation method which can be used successfully with the devices described herein. This method of monitoring the formation of amplification product involves the continuous measurement of PCR product accumulation using a dual-labeled fluorogenic oligonucleotide probe—an approach frequently referred to in the literature as the “TaqMan” method. See U.S. Pat. No. 5,723,591

**[0080]** Molecular Beacons: With molecular beacons, a change in conformation of the probe as it hybridizes to a complementary region of the amplified product results in the formation of a detectable signal. The probe itself includes two sections: one section at the 5' end and the other section at the 3' end. These sections flank the section of the probe that anneals to the probe binding site and are complementary to one another. One end section is typically attached to a reporter dye and the other end section is usually attached to a quencher dye. In solution, the two end sections can hybridize with each other to form a hairpin loop. In this conformation, the reporter and quencher dye are in sufficiently close proximity that fluorescence from the reporter dye is effectively quenched by the quencher dye. Hybridized probe, in contrast, results in a linearized conformation in which the extent of quenching is decreased. Thus, by monitoring emission changes for the two dyes, it is possible to indirectly monitor the formation of amplification product. Probes of this type and methods of their use are described further, for example, by Piatek et al., 1998, *Nat. Biotechnol.* 16:359-63; Tyagi, and Kramer, 1996, *Nat. Biotechnology* 14:303-308; and Tyagi, et al., 1998, *Nat. Biotechnol.* 16:49-53 (1998).

**[0081]** Scorpion: The Scorpion detection method is described, for example, by Thelwell et al. 2000, *Nucleic Acids Research*, 28:3752-3761 and Solinas et al., 2001, “Duplex Scorpion primers in SNP analysis and FRET applications” *Nucleic Acids Research* 29:20. Scorpion primers are fluorogenic PCR primers with a probe element attached at the 5'-end via a PCR stopper. They are used in real-time amplicon-specific detection of PCR products in homogeneous solution. Two different formats are possible, the ‘stem-loop’ format and the ‘duplex’ format. In both cases the probing mechanism is intramolecular. The basic elements of Scorpions in all formats are: (i) a PCR primer; (ii) a PCR stopper to

prevent PCR read-through of the probe element; (iii) a specific probe sequence; and (iv) a fluorescence detection system containing at least one fluorophore and quencher. After PCR extension of the Scorpion primer, the resultant amplicon contains a sequence that is complementary to the probe, which is rendered single-stranded during the denaturation stage of each PCR cycle. On cooling, the probe is free to bind to this complementary sequence, producing an increase in fluorescence, as the quencher is no longer in the vicinity of the fluorophore. The PCR stopper prevents undesirable read-through of the probe by Taq DNA polymerase.

**[0082]** Invader: Invader assays (Third Wave Technologies, Madison, Wis.) are used particularly for SNP genotyping and utilize an oligonucleotide, designated the signal probe, that is complementary to the target nucleic acid (DNA or RNA) or polymorphism site. A second oligonucleotide, designated the Invader Oligo, contains the same 5' nucleotide sequence, but the 3' nucleotide sequence contains a nucleotide polymorphism. The Invader Oligo interferes with the binding of the signal probe to the target nucleic acid such that the 5' end of the signal probe forms a “flap” at the nucleotide containing the polymorphism. This complex is recognized by a structure specific endonuclease, called the Cleavase enzyme. Cleavase cleaves the 5' flap of the nucleotides. The released flap binds with a third probe bearing FRET labels, thereby forming another duplex structure recognized by the Cleavase enzyme. This time the Cleavase enzyme cleaves a fluorophore away from a quencher and produces a fluorescent signal. For SNP genotyping, the signal probe will be designed to hybridize with either the reference (wild type) allele or the variant (mutant) allele. Unlike PCR, there is a linear amplification of signal with no amplification of the nucleic acid. Further details sufficient to guide one of ordinary skill in the art are provided by, for example, Neri, B. P., et al., *Advances in Nucleic Acid and Protein Analysis* 3826:117-125, 2000) and U.S. Pat. No. 6,706,471.

**[0083]** Padlock probes: Padlock probes (PLPs) are long (e.g., about 100 bases) linear oligonucleotides. The sequences at the 3' and 5' ends of the probe are complementary to adjacent sequences in the target nucleic acid. In the central, noncomplementary region of the PLP there is a “tag” sequence that can be used to identify the specific PLP. The tag sequence is flanked by universal priming sites, which allow PCR amplification of the tag. Upon hybridization to the target, the two ends of the PLP oligonucleotide are brought into close proximity and can be joined by enzymatic ligation. The resulting product is a circular probe molecule catenated to the target DNA strand. Any unligated probes (i.e., probes that did not hybridize to a target) are removed by the action of an exonuclease (which may be introduced before or after a pooling step). Hybridization and ligation of a PLP requires that both end segments recognize the target sequence. In this manner, PLPs provide extremely specific target recognition.

**[0084]** Using universal primers, the tag regions of circularized PLPs can be amplified and resulting amplicons detected. For example, TaqMan real time PCR can be carried out to detect and quantitate the amplicon. The presence and amount of amplicon can be correlated with the presence and quantity of target sequence in the sample. For descriptions of PLPs see, e.g., Landegren et al., 2003, Padlock and proximity probes for in situ and array-based analyses: tools for the post-genomic era, *Comparative and Functional Genomics* 4:525-30; Nilsson et al., 2006, Analyzing genes using closing and replicating circles *Trends Biotechnol.* 24:83-8; Nilsson et